ATTENTION

- ALWAYS INSTALL SEGNUT WITH WASHER.
- CHECK BOLT THREAD IS VISIBLE PAST NUT.
- TIGHTEN/LOOSEN USING INNER.
- TIGHTEN FIRMLY WITH HAND TOOL FIRST IF USING A RATTLEGUN.
- RELEASE USING OUTER. SEGMENTS CAN THEN BE KNOCKED FREE WITH HAMMER/ RATTLEGUN. ENSURE EYE PROTECTION AND OTHER PPE IS WORN DURING RELEASE PROCESS.





